

# How can I send data to ibaPDA via TCP/IP?

ibaPDA provides several protocols. ibaPDA can be TCP/IP server as well as TCP/IP client, i.e. it can either wait for incoming connections or initiate the connection itself.

If you're using Generic-TCP/IP you can send unformatted data records. Other protocols such as VIP, MODBUS or SISTEAM need firm data structures.

Unique solution ID: #1120

Author: Holger Benkhart

Last update: 2018-12-13 11:30